Using FON-350i/360i Telephones with FortiVoice Enterprise Systems



The reference card includes the basic features. For more information, see the phone's user guide.

Buttons

Most of the buttons are similar to those on other phones, but you might not be familiar with the following:

— Puts a call on hold.

— Toggles do not disturb on or off

☐/(→ — Opens configuration options or transfers a call

Softkeys — The screen shows the current function of each of the 3 softkeys. Softkeys change based on the call status.

Remember

Press # or Dial after dialing an outside number or extension.

Setting up voicemail

- 1. Press Vmail.
- 2. When prompted, enter a password, record a greeting and record your name for the dial-by-name directory.

Checking voicemail

- 1. Press Vmail.
- 2. When prompted, enter your password + # .
- Press to listen to your messages. You can also change your greeting and personal options.

Calling an outside number

- 1. Dial the phone number + # or press Dial.
- 2. If prompted, dial an access code.

Calling an extension

Dial the extension number + ## or press *Dial*. You can also press an extension appearance key if programmed to monitor a specific extension.

Placing a caller on hold

Press or *Hold*. You can now hang up or answer another call without disconnecting the caller.

Retrieving a caller on hold

Press or *Resume*. You can also press the flashing extension or line appearance key if it's associated with the call on hold.

Performing a screened transfer

A screened transfer allows the recipient to accept or refuse the transfer.

- 2. When the recipient answers:
 - press *Transfer* or hang up to complete the transfer or
 - press EndCall, then Resume to retrieve the caller on hold and cancel the transfer.

Performing a blind transfer

Press $|| / (+ \cdot +$ < extension> (or outside number) + *Dial*, and hang up.

Key states

Light	Status
Flashing green (rapid)	Incoming call
Solid green	This extension is in use
Flashing green (slow)	Call on hold at this extension
Solid red	Line/extension/queue in use
Flashing red (slow)	Line/extension/queue on hold
Alternating red and yellow	Extension/line not registered
Solid yellow	Do No Disturb (DND) enabled

Voicemail

Access mailbox:	
Locally	Vmail
Remotely	X 9 8 #
Go to old messages	2
Change personal options	0
(greetings, password, remote no	otification options)

MESSAGE DI AVRACK CONTROI S

Go to first message	1	
Restart	2	
Go to end	3	
Play previous message	4	
Play next message	6	
Delete message	7	
Forward message	8	
Save message	9	
Evit	#	



Using FON-350i/360i Phones with FortiVoice **Enterprise Systems**

Accessing Features

Press 🖱 to toggle on/off. Do not disturb

Pick up: Any ringing extension

Press Pickup (if programmed),

or * 8 0 + #

Pick up: Specific extension

Press the key associated with the extension.

or * 8 1 + <extension> + # .

Place caller on hold Retrieve caller on hold

or the flashing key associated with the call on hold



Accessing Features			
Answer call waiting		Answer or the flashing line appearance key.	
Screened transfer		on> (or outside number) + ## + Transfer, or hang up. fer, EndCall + Resume to connect to the caller on hold.	
Blind transfer	■ / (→• +	<extension> (or outside number) + Dial, and hang up.</extension>	
Voicemail transfer		(+• + ★ + <extension> + Dial, and hang up.</extension>	
Conference call	Call the second party (for	More + Conf. to put the first party on hold. external calls, first access an outside line). Press Join.	
Park a caller	Р	ress the programmed <i>Park</i> or / (+• + * 4 + # . The system will respond with a parking orbit.	
Two-way intercom paging to FortiFone telephones			
	P	ress the programmed $Intercom + <$ extension> + $Dial$, or 3 9 2 + $<$ extension> + 4 .	
Two-way group paging to FortiFone telephones		Dial the <paging group="" number=""> + $\#$.</paging>	

FON-350i-360i_ref_card_for_FVE Revision 1 201608